




# Installation Tool - Solid - Inch

for threaded inserts TR1698 & TR1696

Installation  
Tools



**TR1730**

INSTALLATION TOOLS

**Material**

Steel, blackened.

**Tips**

For use with inch solid inserts TR1698

**and TR1696.**

Select installation tool of corresponding insert external thread  $d_1$ . If in doubt refer to data tables of insert where correct „Inst.

tool ref.“ is stated.

Order No.	For insert of external thread = $d_1$	Thread type $d_1$
TR1730.0010	5/16"-18	UNC
TR1730.0020	3/8"-16	UNC
TR1730.0030	7/16"-14	UNC
TR1730.0040	1/2"-13	UNC
TR1730.0050	9/16"-12	UNC
TR1730.0060	5/8"-11	UNC
TR1730.0065	11/16"-11NS	UNF
TR1730.0070	3/4"-16	UNF
TR1730.0075	13/16"-16	UNF
TR1730.0080	7/8"-14	UNF
TR1730.0090	1"-12	UNF
TR1730.0100	1-1/8"-12	UNF
TR1730.0110	1-1/4"-12	UNF
TR1730.0120	1-3/8"-12	UNF